


























Caution: This instruction manual is intended for universal reference, slight variations in part dimensions are normal. (Manual Number: 602-09-0484)

COMPONENT							
①	②	③	④	⑤	⑥	⑦	⑧
							
X22	X12	X2	X10	X4	X4	X1	X1
P1	P2	P3	P4				
							
X2	X1	X2	X2				
P5	P6	P7					
							
X2	X1	X1					
P8	P9	P10					
							
X1	X1	(Mousepad) X1					
P11	P12	P13	P14				
							
X2	X2	X2	(Stickers) X2				


1


①  x 4

P6 P7 P13

! Before tightening the screws, you must ensure that the two desktop pieces are aligned and flush against each other.


2

②  x 4

⑥  x 4


P5 P11


3

①  x 16

P12


4

②  x 8


④  x 2

P1 P2


5




6




7





8



9



ACCESSORY



CONTACT US

1. Tel: 844-416-2090
 2. Website: www.eurekaergonomic.com
 3. E-mail: customerservice@eurekaergonomic.com

联系我们

咨询电话: 18144956470
 官方网址: www.designa.cn
 在线客服: 请登录京东商城搜索易瑞康、赛途官方旗舰店